



Index No.	Part No.	Description	Qty.	Index No.	Part No.	Description	Qty.
<b>A</b>	<b>8940168843</b>	<b>Housing kit</b>		<b>E</b>	<b>8940168848</b>	<b>Gear kit</b>	
1		Motor Housing	1	19		Spacer	1
34		Rubber Grip	1	22		Internal Gear	1
<b>B</b>	<b>8940168844</b>	<b>Inlet KIT</b>		26		Work Spindle	1
3		Air Inlet	1	28		Ball Bearing	2
31		Exhaust Deffuser	1	29		Washer	1
32		Screw	2	<b>E1</b>	<b>8940168849</b>	<b>Planet Gear KIT</b>	
<b>C</b>	<b>8940168845</b>	<b>Trigger kit</b>		23		Planet Gear (set of 3)	1
2		Spring Pin	1	24		Pin	3
4		Trigger	1	25		Needle Bearing	3
5		Valve Stem	1	<b>F</b>	<b>8940168853</b>	<b>Spindle Kit</b>	
6		Reverse Bushing	1	35		Spindle Assembly	1
7		O-Ring	1	36		Set of screw	1
8		Valve Srping	1	33	2050485443	Clamp Nut	1
9		O-Ring	1	<b>G</b>	<b>8940168856</b>	<b>Handle Kit</b>	
10		Reverse Lever	1	37		Handle (optional)	
30		O-Ring	1	38		Retainer (optional)	
<b>D</b>	<b>8940168846</b>	<b>Motor Kit</b>			6158727610	Warning label	
11		Motor Gasket	1		6158727620	Warning label	
15	2050485903	Rotor	1		6158727630	Warning label	
16	2050485913	Rotor Blades (Set Of 5)	1		2050507773	Tune up kit (7,9,13,16,25,28,30,11,17)	
17		Spring Pin	1				
18	2050485933	Cylinder	1				
<b>D1</b>	<b>8940168847</b>	<b>End Plate Kit</b>					
13		Ball Bearing	2				
14		End Plate	2				

	6159948700	SAFETY INSTRUCTIONS
	8940168823	OPERATOR'S MANUAL
	8940168670	EC DECLARATION