



| Pos. | Artikelnr. | Description | Anz. | Pos. | Artikelnr. | Description | Anz. |
|------|------------|---|------|------|------------|-------------------|------|
| 1 | 8940174796 | Front housing RC250 | 1 | 9 | 8940171793 | Test unit | 1 |
| | 8940174797 | Front housing RC500 | 1 | 10 | 8940174810 | Power socket | 1 |
| 2 | 8940174799 | Front cover | 1 | 11 | 8940174811 | Buzzer alarm | 1 |
| 3 | 8940174802 | Ultracapacitor unit RC250 | 1 | 12 | 8940167815 | Circuit breaker | 1 |
| | 8940174803 | Ultracapacitor unit RC500 | 1 | 13 | 8940172711 | Main switch | 1 |
| 4 | 8940167817 | Clamp holder | 2 | 14 | 8940174812 | Fuse | 1 |
| 5 | 8940167816 | Cable holder | 2 | 15 | 8940174813 | Switching adapter | 1 |
| 6 | 8940174804 | Rear housing RC250 | 1 | | 8940174814 | Screws kit | 1 |
| | 8940174805 | Rear housing RC500 | 1 | | | | |
| 7 | 8940174808 | Negative (black) clamp with cable RC250 | 1 | | | | |
| | 8940174806 | Negative (black) clamp with cable RC500 | 1 | | | | |
| 8 | 8940174809 | Positive (red) clamp with cable RC250 | 1 | | | | |
| | 8940174807 | Positive (red) clamp with cable RC500 | 1 | | | | |



8956001318

Operator's manual & safety instructions

8950900061

Warning label